

[Home](#) > Generally, the lower side is kept “Tight side” and upper side is kept as “Slack side” with the belt drives having small driving pulley and big driven pulley. Why ?

Generally, the lower side is kept “Tight side” and upper side is kept as “Slack side” with the belt drives having small driving pulley and big driven pulley. Why ?

Question:

Generally, the lower side is kept “Tight side” and upper side is kept as “Slack side” with the belt drives having small driving pulley and big driven pulley. Why ?

Answer:

Power transmission in belt drive depends on angle of lap and frictional grip between belt and pulley. As slack side is at upper side angle of lap and grip increases.
